



SUPPLEMENT TO THE INSTRUCTION MANUAL

1. CONNECTING JRL-2000F TO NON-JRC EXCITERS






The following pin connection diagrams indicate the proper wiring to be used if the JRL-2000F is to be operated with a some current, non-JRC transceivers.

YAESU

ICOM



KENWOOD



Note: Japan Radio Company assumes no responsibility for damage incurred by improper connection.